





## CVe Monitor Initialization


**1** 


**2** 


**3** 


**4** 

Idle Time (default = 201 seconds)  
Sleep Time (default 360 minutes) prepopulates.

**5** 

**6** 

**7** 

**8** 

For complete OnDemand software instructions, please refer to the User Guide.  
For technical assistance please email: [helpdesk@asttech.com](mailto:helpdesk@asttech.com).